


RE-PROGRAMMING A KEYFOB TO A RECEIVER

(PLEASE READ THE INSTRUCTIONS BEFORE ATTEMPTING TO REPROGRAMME)

STEP 1 ERASE THE TRANSMITTER

- 1 REMOVE THE COVER FROM THE BLUE RECEIVER BOX.
- 2 PRESS & HOLD DOWN THE FUNCTION BUTTON **A** UNTIL THE RED LIGHT GOES OUT, THIS IS LOCATED AT THE TOP RIGHT HAND SIDE OF THE RECEIVER BOX.
- 3 THE RECEIVER BOX IS NOW READY TO BE RE-PROGRAMMED TO THE KEYFOB.



STEP 2 RE-PROGRAMME THE KEYFOB

- 1 PRESS & RELEASE FUNCTION BUTTON **A** ONCE, THE RED LIGHT IN THE RECEIVER BOX WILL LIGHT UP.
- 2 TURN ON THE KEYFOB BY PRESSING THE RED BUTTON, THE RED LIGHT WILL LIGHT UP.
- 3 PRESS AND HOLD THE FUNCTION BUTTON **B** FOR 3 SECONDS, THE RED LIGHT IN THE RECEIVER BOX SHOULD FLASH TWICE NOW THE KEYFOB SHOULD BE RE-PROGRAMMED.

